


FIGURE 1



200

FIGURE 2

SEND ATM-TOM correlation tag AND ATM SOURCE ID
FROM ATM SOURCE GATEWAY TO TELEPHONY
SIGNALING CONTROL NETWORK 301

SEND ATM-TOM correlation tag AND ATM SOURCE ID
FROM TELEPHONY SIGNALING CONTROL NETWORK
TO ATM DESTINATION GATEWAY 302

SEND SETUP MESSAGE WITH ATM-TOM correlation tag FROM
ATM DESTINATION GATEWAY TO ATM SOURCE
GATEWAY

303

FIGURE 3